

48300KITS/48314KITS (JK BMS) Assembly Instructions



WARNING:

If any parts are missing, damaged or worn, stop using this KITS. Repair the KITS with manufacturer supplied parts.

IMPORTANT:

Read these instructions carefully before beginning assembly. Failure to follow these instructions may result in serious injury.

Carefully unpack all parts and identify them with the parts list before attempting to assemble the KITS. Remove all cardboard and plastic covering from DIY KITS parts.

Please examine all packing material before discarding it.


ALL DIY KIT accessories are included in the DIY box.



Wire pre-installation

When receiving the 48V kits accessories, the customers need to check whether the collection line of PCB bars is wrong inserted or not, it means that PCB1 and PCB2 have assembly errors, PCB 1/A and PCB 2/B board are marked, as shown in the following picture:

PCB 1/A




PCB 1/A board is marked with wires, they are B-, B1, B2, B3, B4, B5, B6, B7, B8, NTC1, GND, NTC2, There are 12 lines on the collector terminal;

You must confirm the wiring before inserting, or else it will damage the BMS, and we won't provide after-sales service.

Note:

Please make sure that the goods you receive are as follows. If you receive the goods and they are inconsistent with the picture, you should report to our customer service in time. Do not assemble them without permission.



Packing list


Please check the product carefully after receiving it, if any accessories are missed, please contact BASEN.



A (Pre-installed)
Shell*1




B (Pre-installed)
Cover plate*1



C (Pre-installed)
PCB bars*2
(integrated with
Temp NTC leads)



D (Pre-installed)
Front plate*1, Handle*2



E (Pre-installed)
LCD Display*1



F (Pre-installed)
JK 16S 200A BMS*1



G
Fire extinguishing
aerosol*2



H (Pre-installed)
16S voltage
acquisition cable*1




I
Fiberglass
Insulation plate*24



J
EVA cotton*4



K
Screws*32



L
Flexible busbar*15




M
Inverter
communication cable*1



N
USB-RS485
communication cable*1



O
Parallel
communication cable*1



P
Toggle Latch
Ring Pull*2

Install video: <https://youtu.be/GBZCqZVvyl8>



Remove the cover plate(B)



Remove the PCB bars(C)




Remove the BMS front plate(D)

Put the fiberglass insulation plate(I) and EVA cotton(J)







Cells Voltage difference $\leq 20\text{mV}$



Place the battery cells in the chassis, separated by fiberglass insulation plate (I)


Ensuring the positive and negative terminals are in the correct positions.

Link the PCB bars(C) and flexible busbar(L), then screw up(Torque: 6 Nm)






PCB 1/A



PCB 2/B





Noticed: When plugging the voltage sampling line, first, it is always need to plug in the line located on the PCB1/A side (B-), and then insert the line located on the PCB2/B side (B+)

Link the Cable of LCD screen(E) and install into the Front plate(D)



















Check every connection, the voltage between the main positive and the negative is $>52V$, then turn the button on, the LCD and the indicator work out, then the assembly operation is completed.



P.S.: It is recommended to do 1-2 times of complete cycle (fully charged and discharged) in the first running of the battery pack.

Please refer to the table below to set the DIP switch for parallel connection of different batteries.

4-BIT					
Address	Dip Switch Position				Illustration
	#1	#2	#3	#4	
0	OFF	OFF	OFF	OFF	
1	ON	OFF	OFF	OFF	
2	OFF	ON	OFF	OFF	
3	ON	ON	OFF	OFF	
4	OFF	OFF	ON	OFF	
5	ON	OFF	ON	OFF	
6	OFF	ON	ON	OFF	
7	ON	ON	ON	OFF	
8	OFF	OFF	OFF	ON	
9	ON	OFF	OFF	ON	
10	OFF	ON	OFF	ON	
11	ON	ON	OFF	ON	
12	OFF	OFF	ON	ON	
13	ON	OFF	ON	ON	
14	OFF	ON	ON	ON	
15	ON	ON	ON	ON	






Important: In a parallel system, every battery must have a unique DIP switch address between 1–15. Duplicate addresses will cause communication failure.


Operation of Upper PC Software

Download: <https://www.basenpower.com/download/>

The screenshot shows the 'DOWNLOAD CENTER' page with a navigation menu including 'Residential Energy Storage Battery', 'CAI Energy Storage Solution', 'LiFePO4 Golf Cart Battery', '12V/24V LiFePO4 Battery', 'DIY Kit', 'Brochure', and 'Software'. The 'Software' button is highlighted with a red arrow. Below, the 'Software-JK BMS' section features a screenshot of the 'JK-BMS-MONITOR 3.8.0' software interface and a download button for 'jk-bms-monitor-3.8.0-setup.exe'.

Firstly, connect the USB to RS485 Cable from Battery to the PC/Laptop, dip switch 1 on the front plate, download the PC software and open it. Secondly, modify the language, and check the status of the battery pack





Password: 66666 or 888888

JK-BMS-MONITOR 3.8.0

Realtime **Settings** Control Logging Detail Logs About Parallel

Li-ion Lifepo4 Lto Export Import Send Batch Verify PWD.

Basic Settings

Cell Count: 16	Send	Calibrating Volt. (V): 52.649	Send
Battery Capacity (Ah): 300	Send	Calibrating Curr. (A): 0.0	Send
Balance Trig. Volt. (V): 0.01	Send	BLE Name: 506177F49010452	Send

Advance Settings

Start Balance Volt. (V): 3.0	Send	Charge UTP (°C): -10.0	Send
Max Balance Cur. (A): 2.0	Send	TMP Stop Heating (°C): 0	Send

Device Id: 1 Port Name: COM6 Comm. Status: Connected Disconnect

JK-BMS-MONITOR 3.8.0

Realtime **Settings** Control Logging Detail Logs About Parallel

Li-ion Lifepo4 Lto Export Import Send Batch Modify PWD.

Basic Settings

Cell Count: 16	Send	Calibrating Volt. (V): 52.649	Send
Battery Capacity (Ah): 300	Send	Calibrating Curr. (A): 0.0	Send
Balance Trig. Volt. (V): 0.01	Send	BLE Name: 506177F49010452	Send

Advance Settings

Start Balance Volt. (V): 3.0	Send	Charge UTP (°C): -10.0	Send
Max Balance Cur. (A): 2.0	Send	TMP Stop Heating (°C): 0	Send

Device Id: 1 Port Name: COM6 Comm. Status: Connected Disconnect

JK-BMS-MONITOR 3.8.0

Realtime **Settings** Control Logging Detail Logs About Parallel

Li-ion Lifepo4 Lto Export Import Send Batch Modify PWD.

Continued Charge Curr. (A): 200.0	Send	UART1 Protocol No.: 005 - PYLON_low_voltag	Send
Charge OCP Delay (s): 3	Send	UART2 Protocol No.: 001 - JK BMS RS485 Mod	Send
Charge OCPR Time (s): 60	Send	UART3 Protocol No.: 015 - JK BMS PBxx SERIE	Send
Continued Discharge Curr. (A): 200.0	Send	CAN Protocol No.: 004 - Victron_CANbus_BMS	Send
Discharge OCP Delay (s): 300	Send	LCD Buzzer Trigger: 09 - MOSFET Over Tempe	Send
Discharge OCPR Time (s): 60	Send	LCD Buzzer Trigger Val: 100	Send

Device Id: 1 Port Name: COM6 Comm. Status: Connected Disconnect

Operation of Bluetooth

DIY KIT is equipped with a Bluetooth function, supports APP monitoring battery statuses. All information available in the battery, such as the state of charge, voltage, operating current, temperature, and other operating information are transmitted in real-time via the Bluetooth transmitter. The parameters can be made visible with the JK BMS App.

Download: Android: "JK BMS" in Play Store


iOS: "JK BMS" in Apple Store

1. For Android users, please visit the Google Play Store and search for 'JK BMS'. For iOS users, go to the Apple Store and look up 'JK BMS'.




2. Turn on the Bluetooth function, then open the Bluetooth APP. Tap the icon in the upper-left corner to check the available device. Then select the device name you want to connect to. When connecting for the first time, the APP will prompt you to enter a pairing password. The default pairing password of the device is "1234". After the device is connected, the APP will automatically save the password, so you will not need to enter it again the next time.

Once connected, you can enter the real-time status interface to check the device status, as shown in the figure below.




3. Go to setting page to modify the "start balance volt", The default password is "888888", before using the battery, please change the value to 3.45V (important).

Please note that unauthorized modification of parameters that results in damage to the BMS/battery will not be covered under warranty.




Operation of Communication Protocol Switch (Via Bluetooth App)



From setting part, it is support change the communication protocol (UART 1 protocol/CAN protocol=RS485/CAN)



Communication Protocol Switching via Screen



Operation of Communication Protocol Switch(Via PC Software)
















Communication Compatible List

BASEN GREEN

深圳市贝森科技有限公司
Shenzhen Basen Technology Co.,Ltd

JK BMS Inverter Communication Protocol Matching Table

Inverter Brand	Communication method	Protocol Name	Communication Potter rate	Interface Definition
维克托-Victron 	CAN	Victron-CAN BUS BMS-V1.00-201707	500K	7H、8L
古瑞瓦特-SPF Growatt-SPF 	485	Growatt BMS-RS485-protocol-1xSxxP_ESSL_V2.01 Growatt BMS-RS485-protocol-V2.0	9600	1B、2A
古瑞瓦特-SPF Growatt-SPF 	CAN	Growatt BMS CAN-Bus-protocol-low-voltage-V1.05	500K	4H、5L
德业 Deye 	CAN	Deye LV-CAN communication protocol	500K	4H、5L
固德威-Goodwe 	CAN	Goodwe-CAN-V1.7-220228-SolarinverterFamily-EN	500K	4H、5L
日月元-Voltronic Power 	485	Voltronic Power-485-V1.03-200325	9600	3B、5A
派能-Pylontech 	485	Pylon-485-V3.5-161216-low voltage protocol	115200	1B、2A
派能-Pylontech 	CAN	Pylon-CAN-V1.2-180408-lowVoltage	500K	4H、5L
硕日-Srne 	485	shuori BMS Modbus Protocol for RS485 V1.3(2020-11-24)	9600	7A、8B
美世乐 Must 	CAN	PV1800F-CAN communication Protocol1.04.04	100K	6H、5L
艾思玛 SMA 	CAN	SMA-CAN-V1.0.0-210630-FSS-ConnectingBat-TI-en-20W	500K	4H、5L
英威腾 INVT 	CAN	Pylon-CAN-V1.2-180408-lowVoltage	500K	4H、5L
首航-SOFAR 	CAN	SOFAR-CAN-V1.00-211117-Rev6	500K	1H、2L

Need additional information?

Just Contact BASEN!

BASEN GREEN

BASENGREEN
YOUR RELIABLE POWER



Web: www.basenpower.com



Fax: (+86)0755-84737145



Tex: (+86)130 0887 9993



Email: info@Basengroup.com



Shenzhen Basen Technology Co., Ltd.



Add: Room 303, Building 3, 1980 Culture and Technology Industrial Park,
Donghuan Road, Longhua District, Shenzhen